



bigleaf
networks

Installation Guide

High-Availability Service



Thank you for choosing Bigleaf!

Your Internet optimization service is only a few steps away! This booklet will walk you through the setup process to get your Bigleaf service up and running. The equipment shipped to you is pre-configured and ready for use, so you can install it right away.

Tech Support: (888) 244-3133

If you have any trouble connecting or you think there may be a problem with your Bigleaf service, please call us so we can help you immediately. For a routine request like a DNS change, feel free to email us.

Bigleaf Dashboard: app.bigleaf.net

(888) 244-3133 / +1 (503) 985-8298 / support@bigleaf.net / www.bigleaf.net

PREP

Begin here when you are ready to get started. Before proceeding, verify that your Configuration Details card is included with your shipment.

1 Prepare Equipment



Gather Network Cables

Gather the needed number of CAT5e, CAT6, or Fiber patch cables to connect from the Bigleaf switches to each ISP modem or router, from switch to switch, and also to your firewall(s) or router(s). You will need 12 to 18 cables, depending on your specific setup.



Plan your power source

During the setup process, you will need to plug the Bigleaf routers and switches into a power source. We strongly recommend utilizing two Uninterruptible Power Supplies (UPS), connecting one router and one switch to each. This will protect the router from power surges and brownouts.



Verify access to your firewall or router

Before you start the setup process, verify that you have access to edit your firewall or router configuration. It will need to be updated with your new Bigleaf IP addresses in Step 9.

2 Consider IP-related Changes

The following considerations may apply to some customers. If none of these apply, you may proceed to the Install section.



DNS Records

Do you have DNS records pointing at your existing ISP IP addresses? If so, you will need to plan to update those to your new Bigleaf IP addresses during the router install. A day or two before the install, you should lower the TTL for those records to a small value like 10 minutes to ensure a quick transition.



Mail Server

Are you hosting a mail server on-site? If so, Bigleaf will need to set up a reverse-DNS PTR record for the server. In order for us to set this up, email support@bigleaf.net with:

- The Bigleaf IP address that you will use for your mail server
- The full hostname of the mail server



VPNs

Do you have any VPNs, or other network resources that are statically configured with WAN IP addresses? If so, prepare to update these during Step 10 of the Install section.

INSTALL

Once you have completed all necessary prep steps, follow these steps to get your Bigleaf service up and running.

3 Get to Know the Bigleaf Switches


Use this overview to familiarize yourself with the general switch connection process. Steps 4 through 7 will provide a step-by-step breakdown of all hardware connections.

The Bigleaf Switches

Each port on a Bigleaf switch is designated for a specific device, as displayed to the right. Both Switch 1 and Switch 2 use this configuration.

Note that not all switch ports will be used on both switches. Non-redundant connections, such as ISP circuits and non-LACP enabled devices, will be staggered between the two switches in case of switch failure.

*Ports 8 and 9 on both switches provide standard Ethernet connections. These ports can be used for firewalls that do not support LACP or for other network devices (such as a laptop used for testing). Please note that spanning tree is not enabled on these ports, so take care not to create a loop between the two switches. If you change your firewall setup and need any updates to the switch configuration, please let us know.



Connection Steps

The subsequent pages will cover Steps 4 through 7 in greater detail.

The number of connections in Step 6 will vary with your WAN configuration. Please see your Configuration Details card for your WAN assignments.

Step 7 has two main options for connecting your firewall(s). You can use LACP for maximum redundancy, or single Ethernet connections if your firewalls do not support LACP.

Connection Types

- SWITCH 1
- SWITCH 2
- SWITCH-TO-SWITCH

- Step 4** Switches
 - A Switch 1, Port 10 to Switch 2, Port 10
 - B Switch 1, Port 11 to Switch 2, Port 11
- Step 5** Bigleaf Routers
 - C Switch 1, Port 0 to Router 1, Port WAN 1
 - D Switch 1, Port 1 to Router 2, Port WAN 1
 - E Switch 2, Port 0 to Router 1, Port WAN 2
 - F Switch 2, Port 1 to Router 2, Port WAN 2
 - G Switch 1, Port 2 to Router 1, Port WAN 3
 - H Switch 1, Port 3 to Router 2, Port WAN 3
 - I Switch 2, Port 2 to Router 1, Port WAN 4
 - J Switch 2, Port 3 to Router 2, Port WAN 4
- Step 6** ISP Modems
 - K Switch 1, Uplink 0 to ISP Modem 1
 - L Switch 2, Uplink 1 to ISP Modem 2
 - M Switch 1, Port 4 to ISP Modem 3
 - N Switch 2, Port 5 to ISP Modem 4
- Step 7** Firewalls
 - O Switch 1, Port 6 to Firewall 1, Port WAN 1
 - P Switch 1, Port 7 to Firewall 2, Port WAN 1
 - Q Switch 2, Port 6 to Firewall 1, Port WAN 2
 - R Switch 2, Port 7 to Firewall 2, Port WAN 2
 - or
 - S Switch 1, Port 8 to Firewall 1, WAN Port
 - T Switch 2, Port 9 to Firewall 2, WAN Port

Option 1


Option 2

4 Connect Switches Together

Using Ethernet cables, connect the two switches together. The switch-to-switch connections allow the switches to function as a unified pair for redundancy. This step is critical to ensure proper operation of the HA system.

SWITCH-TO-SWITCH CONNECTIONS

- A Switch 1, Port 10 to Switch 2, Port 10
- B Switch 1, Port 11 to Switch 2, Port 11



DO NOT PROCEED

until you have completed this step. Failure to connect the switches together will result in reduced redundancy and improper operation.

5 Connect Bigleaf Routers to Switches


Connect the Bigleaf routers to the switches as outlined below (connections C through J).

SWITCH 1 CONNECTIONS

- C Switch 1, Port 0 to Router 1, Port WAN 1
- D Switch 1, Port 1 to Router 2, Port WAN 1

SWITCH 2 CONNECTIONS

- E Switch 2, Port 0 to Router 1, Port WAN 2
- F Switch 2, Port 1 to Router 2, Port WAN 2




SWITCH 1 CONNECTIONS

- G Switch 1, Port 2 to Router 1, Port WAN 3
- H Switch 1, Port 3 to Router 2, Port WAN 3

SWITCH 2 CONNECTIONS

- I Switch 2, Port 2 to Router 1, Port WAN 4
- J Switch 2, Port 3 to Router 2, Port WAN 4



6 Connect ISP Modems to Switches


Plug each ISP circuit into the correct switch port as assigned on your Configuration Details card. You may have up to four connections. Note that the corresponding uplink SFP ports can be used for fiber hand-offs for WAN 1 and WAN 2.

SWITCH 1 CONNECTIONS

K Switch 1, **Uplink 0** to ISP Modem 1

SWITCH 2 CONNECTIONS

L Switch 2, **Uplink 1** to ISP Modem 2




SWITCH 1 CONNECTIONS

M Switch 1, Port 4 to ISP Modem 3

SWITCH 2 CONNECTIONS

N Switch 2, Port 5 to ISP Modem 4



7 Connect Firewalls to Switches

Choose between LACP or Ethernet hand-off to your firewall(s). Note that Firewall 2 is optional.


Option 1 LACP Hand-off

SWITCH 1 CONNECTIONS

- O Switch 1, Port 6 to Firewall 1, Port WAN 1
- P Switch 1, Port 7 to Firewall 2, Port WAN 1

SWITCH 2 CONNECTIONS

- Q Switch 2, Port 6 to Firewall 1, Port WAN 2
- R Switch 2, Port 7 to Firewall 2, Port WAN 2



Option 2 Ethernet Hand-off*


SWITCH 1 CONNECTIONS

- S Switch 1, Port 8 to Firewall 1, WAN Port

SWITCH 2 CONNECTIONS

- T Switch 2, Port 9 to Firewall 2, WAN Port


*Some firewalls support Ethernet "port redundancy," which you can use by connecting Firewall 1 to Ports 8 on both switches and Firewall 2 to Ports 9 on both switches.



8 Plug Hardware into Power Source

Before proceeding, you may want to refer to the switch connection steps outlined in Step 3 to verify that all cables have been connected to the switches correctly. The enclosed power cables may vary depending on the router/switch models.

Using the ports on the back of the devices, plug the Bigleaf routers and switches into a power source. To keep redundancy, we recommend using two separate power sources with UPS protection.



9 Configure Your Equipment

To connect your network to the Bigleaf service, re-configure your firewall(s) or router(s) that are connected to the switches.

Log in to your firewall or router interface and enable auto-negotiation.

Change your interface settings based on your setup:

LACP

- Enable LACP link aggregation
- Set LACP rate or mode as "fast" if available

Non-LACP Port Redundancy Protocol

Configure that setting in accordance to your firewall's documentation.

Single Ethernet Hand-Off

No action required

Navigate to the page where you set the WAN or Internet IP address. Input the information for the fields listed on your Configuration Details card.

Save and apply the new configuration. You may need to reboot your device(s).


The screenshot shows a web interface titled 'Internet Connection'. It contains five input fields for configuration: 'IP ADDRESS', 'SUBNET MASK', 'DEFAULT GATEWAY', 'DNS1', and 'DNS2'. A mouse cursor is positioned over the 'SUBNET MASK' field. The interface has a dark header and a light background for the form fields.

10 Test Connection and Make Final Updates

You should now be up and running on your Bigleaf service. If you identified any IP-related changes in Step 2, you will make those changes now.

Run a test or two, like browsing to a website, to make sure connectivity is working properly.

If things look good, proceed by changing any DNS records or IP-specific network resources that you identified in Step 2.



CONGRATS

Your setup should now be complete.

About Bigleaf Networks

Bigleaf Networks improves Cloud connectivity and Internet performance. We are a team of telecom and network software professionals who built our SD-WAN optimization and redundancy service based on the natural architecture of leaves. We are dedicated to providing a better Internet experience with simple implementation, friendly support, and powerful technology. Founded in 2013, Bigleaf Networks is investor-backed, offering nationwide service.

Simply Stay Connected.

(888) 244-3133 / +1 (503) 985-8298 / support@bigleaf.net / www.bigleaf.net